

DECO-FLASH®

How to Measure and Order Deco-Flash R227 for frame applications.

- From the interior of the building measure finished drywall to drywall around the existing window. Be sure to check the opening for inconsistencies or “out of square”. Deco-Flash should be ordered using the smallest dimensions to determine the proper fit.



- Exterior trim choice should be stated when ordering the Deco-Flash unit, based on homeowner preference or exterior elevation. Options include: 3 ½” Flat Casing, 3” Brick mold or no casing*.
- *If no casing is ordered, additional cladding or painting should be done by a qualified finish professional.
- To Calculate Muller Window Configurations Inside of Deco-Flash: Use an overall window frame size of 1” smaller than the determined drywall to drywall measurement. In the direction of the muller bar, deduct an additional 1/8” to account for the space required for the clips. (Example: Drywall to Drywall Measured at 73” Width x 72” Height with a Vertical Muller; Overall Frame Size of the Window Configuration is 72” Wide x 70-7/8” High)
- If you require additional measuring information or details on Deco-Flash R227, you can call our information Hot Line at 1-888-329-DECO and one of our installation professionals will be happy to answer your questions.